

The background of the image features a light blue, stylized illustration of interlocking gears. The gears are rendered with a hand-drawn, sketchy texture using parallel lines. A solid blue horizontal band cuts across the middle of the image, containing the text 'SUSPENSION PARTS' in white, bold, sans-serif capital letters.

SUSPENSION PARTS

SUSPENSION PARTS



Part No.
PI -M- 0030
FRONT SPRING PIN

OEM Numbers
370 322 0030



Part No.
PI -M- 0417
HELPER SPRING BRACKET

OEM Numbers
352 325 0417



Part No.
PI -M- 1062
SPACER RING FOR
REAR AXLE TUBE

OEM Numbers
389 325 1062



Part No.
PI -M- 5060
RING NUT FOR
REAR AXLE TUBE

OEM Numbers
389 990 5060



Part No.
PI -M- 2152
NUT FOR REAR AXLE TUBE

OEM Numbers
389 325 2152



Part No.
PI -M- 0080
FRONT AXLE HUB GASKET

OEM Numbers
389 334 0080

NOTE: Items listed in this catalogue are not original.
The only purpose of the O.E.M. references listed is to help our Customers in finding PARTS INTERNATIONAL part number

SUSPENSION PARTS

Part No.

PI -M- 0059

FRONT AXLE HUB GASKET

OEM Numbers

317 334 0059



Part No.

PI -M- 0080

REAR AXLE HUB COVER GASKET

OEM Numbers

650 356 0080



Part No.

PI -M- 0219

LHS SPRING SEAT
92MM

OEM Numbers

624 325 0219



Part No.

PI -M- 0319

RHS SPRING SEAT
92MM

OEM Numbers

624 325 0319



Part No.

PI -M- 0219

LHS SPRING SEAT
108MM

OEM Numbers

625 325 0219



Part No.

PI -M- 0319

RHS SPRING SEAT
108MM

OEM Numbers

625 325 0319



NOTE: Items listed in this catalogue are not original.

The only purpose of the O.E.M. references listed is to help our Customers in finding PARTS INTERNATIONAL part number

SUSPENSION PARTS



Part No.
PI -M- 0603

OEM Numbers
335 325 0603

REAR SPRING SUPPORT



Part No.
PI -M- 0596

OEM Numbers
000 325 0596

REAR SPRING SUPPORT
(HIGH)



Part No.
PI -M- 0896

OEM Numbers
000 325 0896

REAR SPRING SUPPORT
(LOW)